

Operation and maintenance manual

PAN-14 Sensor installation guide

Unit number 0000

Version 2 January 2018



Copyright notice

Copyright© 2014-2017 Panoramic Power Ltd. All rights reserved.

Panoramic Power® is a registered trademark of Panoramic Power Ltd.
All other trademarks are the property of their respective owners.

FCC compliance statement

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio and television reception.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause such interference, which can be verified by turning the device off and on, the user is encouraged to eliminate the interference by one or more of the following measures:

- Re-orient or re-locate the receiving antenna.
- Increase the distance between the device and the receiver.
- Connect the device to an outlet on a circuit different from the one that supplies power to the receiver.
- Consult the dealer or an experienced radio/TV technician.

Warning Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference that may be received or that may cause undesired operation.

Manufacturer information

Panoramic Power Ltd.
15 Atir Yeda St.,
Kfar Saba 4464312, Israel

Telephone: +972-9-7667600

IC compliance statement

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference that may be received or that may cause undesired operation.

A distance of at least 10 cm between the equipment and all persons should be maintained during the operation of the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Une distance d'au moins 10 cm entre l'équipement et toutes les personnes devraient être maintenues pendant le fonctionnement de l'équipement.

Product end of use handling (WEEE) - Waste of Electrical and Electronic Equipment

Panoramic Power is committed to protect the global environment and helping our customers with recycle responsibilities. Disposal of electrical and electronic products must be done according with the local and national regulations. You can return your product to a local collection point.

For information about your disposal or collection points, call your distributor or vendor, or contact support@panpower.com.



Contents

Overview	5
Workflow	5
Unpacking the hardware	5
Safety precautions	6
Mapping the site	6
Installing the sensor	6
Registering the installed sensor	8
Monitoring sensor activity	8
Uninstalling a sensor	8
Sensor specifications	9
Range of rated environmental conditions	10
Certified CTs	10
Troubleshooting	11
Support	11

Overview

This user guide explains how to install the PAN-14 sensors.



PAN-14 Current sensor



Current Transformer (CT)

Workflow

Sensor installation consists of the following steps:

1. Map the circuits. See 'Panoramic Power deployment tool user guide'.
2. Physically attach the sensors and the CTs to the wires.
3. Monitors the proper functioning of the sensors. See 'Panoramic Power deployment tool user guide'.

Unpacking the hardware

Sensors are shipped in 3-unit packs.

CTs are not included and can be bought separately.

Safety precautions

The sensor must be installed only on an insulated conductor.

CTs output/secondary current **must not** exceed 5A.

The sensor and CT should be installed and removed only by a qualified electrician.

Installation must not be performed on a live wire for reasons of safety and random shock hazard. Power supply to the panel must be shut off before and during installation.

The sensor and CT must not be installed lying or touching bus bars or any other non-insulated, exposed conductors.

Installation is possible both on external entry/exit conductors before the terminal strip, as well as both ends of the circuit breaker. The least cramped, most accessible location should be chosen for installation. The sensor should be installed such that the arrow points in the direction of the load.

Caution Protection provided by the equipment can be impaired if used in a manner not specified by the manufacturer.

Mapping the site

See 'Panoramic Power deployment guide'.

Installing the sensor

PAN-14 and the associated current transformer should be installed in a location not accessible to an average user. The voltage and current measurement circuit insulation should be adequate for 300V, CAT III, double/reinforced insulation from mains.

This procedure must be carried out by a certified electrician.

1. Connect the PAN-14 sensor to the CT :
2. Connect the two CT's outputs to the PAN-14 sensor using a 1.0-4.0mm² (12-17 AWG) wires as follows:
 - a. Connect the PAN-14 sensor's terminal marked as '1' to the CT's terminal marked as 'S1' or 'X1'
 - b. Connect the PAN-14 sensor's terminal marked as '2' to the CT's terminal marked as 'S2' or 'X2'



3. Mount the CT on the hot wire:

- a. If the CT is split-core:
Close the CT on the hot wire by disconnecting its two parts, and closing them around the hot wire.
- b. If the CT is solid-core:
Disconnect one of the ends of the hot wire from the panel, insert it through the CT, and then reconnect it to the panel.
- c. In both cases, make sure the CT is placed on the wire so that the direction of current flow on the wire is from the side marked 'P1' or 'H1' on the CT, to the side marked 'P2' or 'H2' on the CT.
Other used CT polarity markings are K for entry and L for exit or Load side (respectively P1 and P2).

4. Make sure the sensor's LED is blinking.



5. Finalize the PAN-14 sensor and the CT's position on the panel:

Maintain a reasonable distance between the CT and the sensor.

- Place the PAN-14 sensor on the side that is closer to the bridge (to avoid RF blocking, make sure the CT is **not** positioned between the sensor and the bridge).
- If possible, attach the PAN-14 sensor with plastic ties.

Important notes

Do not mount the CT on the hot wire before you have already connected the PAN-14 sensor securely to the CT!

If a PAN-14 sensor needs to be replaced **short circuit the CT's outputs to each other** using a length of wire **before** PAN-14 is disconnected!

Do not leave the CT mounted/installed on a hot wire without being short circuited.

It is possible to have both the PAN-14 sensor and the short circuiting wire connected to the CT at the same time.

Registering the installed sensor

See 'Panoramic Power deployment guide'.

Monitoring sensor activity

See 'Panoramic Power deployment guide'.

Uninstalling a sensor

Open the sensor in the way you first opened it and remove it from the cable.

Sensor specifications

Specifications	PAN-14
Physical dimensions	33.8 × 29 × 42.5 mm 1.33 × 1.14 × 1.67 inch
Current input range (from external current transformer)	0-5 ARMS (up to 10 A peak)
Current measurement range	Any applicable range based on CT ratio
Current measurement accuracy (typical, at 25° C)	<2% at I > 2% of full-scale current
Minimum operating current (at input from external current transformer)	0.03 – 0.05 A
AC frequency supported	50 Hz (EU, JPE version) 60 Hz (US, JPW version)
Transmission frequency	434 MHz (EU) 915 MHz (US) 923 MHz (JPE, JPW)
Transmission power (ERP)	0 dBm (Max) -4 dBm (Max – JPE, JPW)
Transmission interval	10 seconds
Safety and EMC certificates	<p>USA & Canada Safety: UL 61010-1 (2012, 3rd Edition), UL 61010-2-030 (1st Edition), CAN/CSA C22.2 No. 61010-1 (2012, 3rd Edition), CAN/CSA C22.2 No. 61010-2-030 (1st Edition) (ETL listed) EMC/Radio: FCC Part 15 subpart B, C</p> <p>Europe Safety: EN 61010-1:2010 (3rd Edition), EN 61010-2-030:2010 (1st Edition) (CE) EMC: EN-ETSI 301489-3 Radio: EN-ETSI 300220-1</p> <p>Japan Radio: ARIB STD-T108</p> <p>World Safety: CB Certification by Intertek, IEC 61010-1:2010 (3rd Edition), IEC 61010-2-030:2010 (1st Edition)</p>
Flammability rating of external enclosure	UL94 V-0
Operating temperature	0 – 50° C
Storage temperature	-20 – 65° C

Range of rated environmental conditions

The unit is intended for indoor use.

The maximum ambient temperature is 50°C.

The maximum relative humidity is 80% at temperatures up to 31°C decreasing linearly to 40% at 50°C.

Altitude up to 2000m

CAT III

Pollution Degree 2

Certified CTs

General notes

- Solid-core or split-core CTs can be used.
- CT's accuracy class should be 0.5% or better.
- Relay CTs, Rogowski coils, or CTs with included burden resistors cannot be used.

The following list includes the CTs that were already tested and approved by Panoramic Power.

Dixsen CTs

- 600A split (model DBP-58)
- 600A non-split rectangular (model MES-62)
- 1000A split (model DBP-58)
- 1000A non-split rectangular (model MES-60)

Veris CTs

- 600A non-split round (BL601)
- 1000A non-split round (BL102)

Magnelab CTs

- 600A split (ICT-2000-600)
- 600A non-split rectangular (CCT-1200-600)
- 1000A split (ICT-2000-1000)

Troubleshooting

If you encounter a problem, first try the following solutions:

Problem	Solution
The sensor is not sending measurements	<p>Make sure the circuit has current.</p> <p>Make sure that the sensor arrow points in the direction of the load.</p> <p>Make sure that the sensor LED is blinking.</p> <p>Make sure the sensors are near enough to the Bridge for the Bridge to receive its signals.</p> <p>Check the reception LED of the Bridge. If it is not blinking it means that it is not receiving signals.</p>

Support

More support can be obtained at

support@panpwr.com